

Sardar Patel Institute of Technology
(Electronics & Telecommunication Department)



OFC

Experiment 1

Name: Abeer Sane

Class: TY EXTC

UID: 2023200101

Batch: A1

DETAILED OBJECTIVE: The primary objective of this laboratory experiment is to measure the Numerical Aperture (NA) of a given optical fibre using the Scientech 2501A TechBook with the associated Numerical Aperture measurement jig. The experiment aims to provide students with hands-on experience in setting up the equipment, performing measurements, and analysing results to determine the Numerical Aperture of the optical fibre accurately. Students are expected to compare theoretical and observed values and comment on the same in inference section.

Prelab, Postlab, Readings and Conclusion:

Reading - Exp 1- o/c

1)	Sr no.	Diameter (w)	Length (L)	Formula
	1	10	1.5	0.316
	2	15	2.3	0.31
	3	20	2.8	0.33
	4	25	3.7	0.32

$$\text{Formula} = \frac{w}{\sqrt{4L^2 + w^2}} \quad \text{NA} = \sqrt{n_1^2 - n_2^2}$$

2) Theoretical

$$n_1 = 1.492$$

$$n_2 = 1.406$$

$$\boxed{\text{NA} = 0.499}$$

$$\text{Error} := \frac{|\text{measured} - \text{actual}|}{\text{actual}} \times 100$$

$$= 35.5\%$$

Conclusion:-

The values achieved by the reading are consistent & we have a average error of 35.5%.

Min
28/1/26
101

Pre-Lab:-

1. NA

Numerical aperture of an OF indicates its ability to collect & guide light. It defines the max angle at which light can enter the fiber & still propagate. Higher NA means more light-gathering capacity.

$$\begin{aligned} \text{Formula} = \text{NA} &= \sin \theta_a \quad \rightarrow \text{acceptance angle} \\ &= \sqrt{n_1^2 - n_2^2} \quad \rightarrow \text{refractive index} \end{aligned}$$

2. Setup & Calibration

Components:- Techbook with power supply & mains cord, optical fibre cable & NA measurement Jig

~~Steps~~

Steps:-

- ① Properly align source & fibre
- ② Clean fibre ends
- ③ Keep screen 1 to the fibre
- ④ Accurate distance & spot diameter readings

3. Challenges & Solutions

③ Misalignment

sol:- to align the components with the help of a proper measuring scale & to avoid extra error

(b) Dirty Fibre Ends

Solⁿ: Clean the reading plate & components necessary before the experiment

(c) Measurement Error

Solⁿ: Taking more readings ~~to also vary~~ to get a better understanding of the actual range of the value

(d) Ambient light

Solⁿ: closing the curtains & performing in low light in order to get sharp light.

Post-Lab:-

1. Data Analysis:-

Done on previous page.

The values of the readings were consisting & same so the readings were accurate

2. Comparison with Theoretical values:

The avg value of readings = 0.32

The Theoretical value = 0.499

was calculated by

$$NA = \sqrt{n_1^2 - n_2^2}$$

The values were close enough with a small % of deviation. This variation may be attributed to measurement errors

such as inaccurate θ_a , improper alignment, divergence.

3. Significance of NA

It determines the light-collecting ability of an optical fibre. Higher NA allows better light coupling but inc. modal dispersion. Thus, NA affects signal strength, BW & overall performance.

4. Improvements & Recommendations

Accuracy can be improved by using a well-collimated laser source, precise alignment of the setup, controlled light conditions & multiple readings.

5. Real World Applications

NA is imp. in fibre optic comm. for efficient light coupling. Proper NA selection reduces signal loss & improves transmission quality in app. like internet comm. & medical imaging.